



ROF45[™] INSTALLATION

OFFSET PIGGY-BACK RED DOT OPTIC MOUNT

IMPORTANT

- ▲ ENSURE YOUR FIREARM IS UNLOADED AND CLEARED PRIOR TO INSTALLING ANY ACCESSORIES.
- ▲ IF YOU HAVE ANY DOUBTS OR QUESTIONS ABOUT THESE INSTALLATION INSTRUCTIONS, WE RECOMMEND YOU HAVE THE WORK DONE BY A QUALIFIED GUNSMITH.

TOOL(S) REQUIRED

- T15 torx (star key) driver
- Optional rifle support
- Optional torque wrench (in-lbs increments)
- Optional thread sealer loctite[™] 222 purple

INSTALLATION

1. Remove the original forward top ring half from the Geissele[®] Super Precision[™] scope mount if it is already installed.
2. Place the ROF 45 on top of the front scope ring base and align the screw holes with the base.
NOTE: If desired, place a small dot of Loctite 222 Purple thread lock on each screw. DO NOT USE any other thread lock.
3. After inserting the original screws into the holes on the ROF 45, tighten each of them in an "X" pattern.
NOTE: Ensure the gaps on either side of the mount are even.
NOTE: If you are using a torque wrench, torque each screw to 15-18 in-lbs.
4. Mount the appropriate mini reflex sight (RMR[™] or Delta Point Pro[™]) onto the top of the ROF 45 mount following the sight manufacturer's instructions.

